


ACN BROADBAND TECHNICAL FAQ


A. How to change your Wi-Fi password / Wi-Fi Username for Tp-link?




1. Connect to the Wi-Fi / LAN Cable,
2. Open the web browser (Google chrome / Firefox). Type in the address bar “192.168.1.1”.
3. tp-link Router will open.



4. The default Password of the device will be “admin”
5. Then enter Login.
6. Click on “**Advanced**”.




7. Click on **Wireless Setting**.
8. To set your Wi-Fi Name click on **SSID** (Service Set Identifier) box.



9. Type your desired Wi-Fi name in the option provided as **“SSID”**.

10. Select channel Width as **40MHz/80MHz**

11. To set your Wi-Fi Password, Click on **“Password”**



12. Enter your desired password. In **“Password”** box, your password length has to be between 8 to 64 characters with at-least 1 Uppercase and 1 Special Character.

13. Set your Security as WPA/WPA2 Personal Encryption as **“AES”**.

14. After giving your Wi-Fi name and Password, click on **“Save”**, Then Click **Ok**, to save your settings. Please Confirm that the **“Disable WLAN Interface / Hide SSID”** option is not checked. This will hide your Wi-Fi from all connected devices.

15. Then Logout Successfully.

www.abhishekcablenetwork.com